

Volkswagen Cabriolet DIY Guide

Brake Master Cylinder & Proportioning Valve Information

Brake Master Cylinder

For reference only – verify what is in your vehicle before buying a replacement!

171-611-015AD	17.46mm No booster	
171-611-019B 171-611-019D	20.64mm No booster	
171-611-019N	20.64mm ATE booster Brake warning light	
171-611-019	1979 – 1984 20.64mm ATE booster	
191-611-019	1984.5 – 1990 20.64mm FAG booster	
1H1-611-019C	1990.5 – 1993 20.64mm	

Brake Proportioning Valve (aka Brake Pressure Regulator)

Load Sensitive

811-614-151

1979 – 1984



This component is no longer available new.
A seal rebuild kit is available from Germany:
<https://www.oldtimer-werk.de>
Kit #SW10566



Pressure Sensitive

533-612-151

1984.5 – 1993
(2 required per vehicle)



Brake Booster (aka Brake Vacuum Servo)

For reference only – verify what is in your vehicle before buying a replacement!

172-612-107B

7"
RHD, carburetor
ATE

Photo Not Available

172-612-107C

8"
RHD, fuel injection
ATE

Photo Not Available



(Cardone #53-5601)

1979-1984
9"
LHD
Bendix



<p>811-612-107A (Cardone #53-5771)</p>	<p>1979 – 1984 7" LHD, carburetor ATE / FAG</p>	
<p>171-612-107G (Cardone #53-5700)</p>	<p>1979 – 1984 9" LHD, fuel injection ATE / FAG</p>	
<p>155-612-107 (Cardone #53-5710)</p>	<p>1984.5 – 1990 9" LHD, fuel injection ATE / FAG</p>	
<p>155-612-107A (Cardone #53-5710)</p>	<p>1990.5 – 1993 9" LHD ATE / FAG</p>	

Brake Booster Vacuum Check Valve

<p>191-611-933A</p>		
<p>171-611-933</p>		
<p>056-129-777 056-129-777A</p>	<p>4mm 7.5mm</p>	