
















# Volkswagen Cabriolet

## DIY Guide: Distributors

Component	Production Notes	Engines	Part Numbers	Photos
Distributor Cap	1981 to October 1984	EN JH	113-905-207C Bosch 03010	
Distributor Cap	November 1984 to January 1987	JH	027-905-207 Bosch 03212	
Distributor Cap	January 1987 to 1989	JH	027-905-207A Bosch 03214	
Distributor Cap	1990 to 1993	2H	051-905-207 Bosch 03368	
Suppression / Grounding Ring	1984 to January 1987 (If without this ring, or wanting to eliminate it, use cap #03214)	JH	059-905-209	
Rotor 14mm	1981 to 1989	EN JH	055-905-225B Bosch 04038	
Rotor 10mm	1990 to 1993	2H	052-905-225C Bosch 04170	
Hall sender	1980 to 1983	EJ EN	035-998-065	
Hall sender	1984 to 1993	JH 2H	035-998-065A 034-998-065	

Distributor	To JH-140000	JH	026-905-205L*	
Distributor	JH-140001 to JH-280000	JH	026-905-206B#	
Distributor	From JH-280001	JH	026-905-205AH#	
Distributor	L-00001 to L-12000	2H	037-905-205+	
Distributor	L-12001 to M-21000	2H	037-905-205F+	
Distributor	From M-21001	2H	037-905-205K+	
<p>* Replacement is 026-905-205L  # Replacement is 026-905-237X  + Replacement is 037-905-237X</p>				